



* DETERMINE CIRCUMFERENCE THAT WILL YIELD DESIRED INSIDE DIAMETER AND CAREFULLY TRIM TYGON SLEEVE BEFORE THREADING FREE END OF TY-WRAP THROUGH THE CLASP